

Extendable pruning shears

## N-381 KARIKICHI NOBINOBI 1000

### Features

- One-touch system makes it easy to extend and retract.
- Ultra-lightweight, aluminum alloy.

### Specifications

Blade length:150mm


Full length:660~1000mm

Weight:890g

### How to operate

- 1) Turn the handle to the left to loosen.
- 2) The handle is extended.
- 3) Turn the handle to the right to tighten.

Loosen



Tighten



Warning

Wrong use may result in electric shock, and/or serious injury or death.

- Do not work at the area of electric shock possibility such as nearby electric wires.
- The blade is very sharp. Do not touch the blade at any time.
- When cutting, branches and tree scraps are falling. In addition, please do not work in the fall point, as the blade parts may fall and cause unexpected injury. In particular, please pay attention to children and pets.
- Use personal protective equipment. Always wear eye-protection, helmet and gloves.
- Keep proper footing and balance. Do not work at unstable position such as roof, stepladder, etc.
- After use, close the blade and keep it out of the reach of children.



Caution

Please be sure to protect

- Please do not use this product for purposes other than its intended use.
- Before use, please inspect for the loosening of the screws and whether there is any damage to the parts, and use after confirming safety.



**NISHIGAKI INDUSTRIAL CO., LTD.**

Extendable pruning shears

## N-381 KARIKICHI NOBINOBI 1200

### Features

- One-touch system makes it easy to extend and retract.
- Ultra-lightweight, aluminum alloy.

### Specifications

Blade length: 150mm


Full length: 760~1200mm

Weight: 1080g

### How to operate

- 1) Turn the handle to the left to loosen.
- 2) The handle is extended.
- 3) Turn the handle to the right to tighten.

Loosen



Tighten



**Warning** Wrong use may result in electric shock, and/or serious injury or death.

- Do not work at the area of electric shock possibility such as nearby electric wires.
- The blade is very sharp. Do not touch the blade at any time.
- When cutting, branches and tree scraps are falling. In addition, please do not work in the fall point, as the blade parts may fall and cause unexpected injury. In particular, please pay attention to children and pets.
- Use personal protective equipment. Always wear eye-protection, helmet and gloves.
- Keep proper footing and balance. Do not work at unstable position such as roof, stepladder, etc.
- After use, close the blade and keep it out of the reach of children.



**Caution** Please be sure to protect

- Please do not use this product for purposes other than its intended use.
- Before use, please inspect for the loosening of the screws and whether there is any damage to the parts, and use after confirming safety.



**NISHIGAKI INDUSTRIAL CO., LTD.**