

Raw wood pruning saw


# N-745 SAYANOKO 330

**Use** ■ For pruning of raw wood

Blade length	Pitch	Thickness	Cutting width
330mm	2.4mm	0.8mm	0.76mm


## How to change the blade

### How to remove the blade



Lightly strike the back of the blade to remove it.


### How to attach the blade



Attach the hook of the replacement blade to the hook bracket of the back metal (①) and push it in the direction of ② to temporarily fix it.



**⚠ Caution Please be sure to observe.**

 The cutting edge may cause injury. Be sure to wear gloves when replacing the blade.

 **NISHIGAKI INDUSTRIAL CO., LTD.**



4 964590 740059

sheath:ABS  
sticker:PP

**MADE IN JAPAN**