

Raw wood pruning saw


N-745 SAYANOKO 330

Use ■ For pruning of raw wood

Blade length	Pitch	Thickness	Cutting width
330mm	2.4mm	0.8mm	0.76mm

How to change the blade

How to remove the blade



Lightly strike the back of the blade to remove it.

How to attach the blade

1) Back metal



Hook bracket Hook

Attach the hook of the replacement blade to the hook bracket of the back metal (①) and push it in the direction of ② to temporarily fix it.



Hit the back metal to fix the blade.

⚠ Caution Please be sure to observe.



The cutting edge may cause injury. Be sure to wear gloves when replacing the blade.

Lebendholz-Astsäge

N-745 SAYANOKO 330

Verwendungszweck

■ Zum Aussägen von Lebendholz


Sägeblattlänge:330mm

Verzahnung:2.4mm Blattdicke :0.8mm

Schnittbreite :0.76mm

Austauschen des Sägeblatts

Abnehmen des Sägeblatts



Zum Abnehmen vorsichtig auf die Rückseite des Sägeblatts schlagen.

Montieren des Sägeblatts

1) Hinterer Metallteil



Hakenbügel Haken

Den Haken des Ersatzsägeblatts am Hakenbügel des hinteren Metallteils (①) befestigen und in Richtung ② drücken, um es provisorisch zu befestigen.



Auf den hinteren Metallteil schlagen, um das Sägeblatt auszurichten.

⚠ Vorsicht



Die Schnittkante kann Verletzungen verursachen. Tragen Sie stets Handschuhe.

ドイツ



NISHIGAKI INDUSTRIAL CO., LTD.