

Raw wood pruning saw

N-745 SAYANOKO 330

Use ■ For pruning of raw wood

Blade length	Pitch	Thickness	Cutting width
330mm	2.4mm	0.8mm	0.76mm

How to change the blade


How to remove the blade



Lightly strike the back of the blade to remove it.



How to attach the blade



Attach the hook of the replacement blade to the hook bracket of the back metal (①) and push it in the direction of ② to temporarily fix it.



Hit the back metal to fix the blade.

⚠ Caution Please be sure to observe.



The cutting edge may cause injury. Be sure to wear gloves when replacing the blade.

Sierra de podar para madera en bruto

N-745 SAYANOKO 330

Objetivo Para podar madera en bruto

Longitud de la hoja :330mm Paso :2.4mm

Espesor :0.8mm Ancho de corte :0.76mm

Cómo cambiar la cuchilla

Cómo quitar la cuchilla



Golpee ligeramente la parte posterior de la hoja para quitarla.



Cómo colocar la hoja



Conecte el gancho de la hoja de repuesto al soporte del gancho del metal posterior ① y empújelo en la dirección de ② para fijarlo temporalmente.



Golpea el metal trasero para fijar la hoja.

⚠ Precaución Por favor asegúrese de observar.



El filo puede causar lesiones. Asegúrese de usar guantes al reemplazar la hoja.

 **NISHIGAKI INDUSTRIAL CO., LTD.**

MADE IN JAPAN HECHO EN JAPÓN