


Fruit Picker Telescopic (N-126/128/129) Parts List



Part No.	Part Name	Image	Part No.	Part Name	Image
N-128-50	Blade Assy (includes blade cover) (for N-128-61, set of 2)		N-128-66	Spring	
N-128-51	Blade Mounting Bolt & Nut		N-107-76	Handle Spring / Rivet / Washer Set	
N-128-52	Handle Assy (incl. N-128-58/62, mounting rivet and washer)		N-128-85	Basket	
N-128-53	Hook Set (N-128-54/55, set of 2)		【Joint Internal Parts】		
N-128-54	Upper Hook Mounting Screw (White Head) Sold Individually		N-128-68	Rack Spring (Large)	
N-128-55	Lower Hook Mounting Screw (+ Head) Sold Individually		N-128-69	Rack Spring (Small)	
N-128-56	Wing Screw for Saw (M4×6)		N-128-70	Joint (Large)	
N-128-57	Side Plate		N-128-73	Joint Rack	
N-128-58	Handle Stopper		N-128-74	Tip Pipe Rack	
N-128-59	Grip Assy (incl. N-128-60 / N-107- 69/70/71)		N-107-69	Grip Round Plate Nut (M4)	
N-128-60	Grip White Screw		N-107-70	Grip Round Plate Fixing Fitting	
N-128-61	Blade Assy Screw		N-107-71	Grip Round Plate Assembly Screw (M2.6×10)	
N-128-62	Handle Mounting Screw		N-128-78	Link Mounting Pin φ4×10	
N-128-63	Upper Blade / Front hook Connecting Screw		N-128-79	Receiver Base	
N-128-64	Handle (Large / Small) Rivet		N-128-80	Joint Large Assembly Screw	
N-135	Saw Blade set (incl. N-128-56)				